C_RTK centimeter positioning system

Description

High-precision positioning: Many drone applications require higher accuracy than traditional GNSS offerings, such as drone mapping, agricultural surveying, and high accuracy takeoff and landing.

C-RTK is a Real Time Kinematics module for mass market launched by CUAV. The complete RTK system can be composed of two C-RTK modules (one for aircraft and one for base station)



Small size, big power

Integrated RTK GPS (M8P) + GNSS system dual positioning module and a COMPASS geomagnetic compass in only 53MMX32MM volume, greatly reducing the installation volume requirements for the aircraft, but also improve the reliability and greatly reduce the hardware cost

CNC aviation aluminum alloy shell

C-RTK uses a CNC formed aluminum alloy shell, in addition to reducing external electromagnetic interference, reliability and durability also have some improvement

Double-ended design

D-The use of TYPE-C interface design, clever use of port redundancy design, the aircraft end and ground end only need to insert different specific data line can be double-ended switching, convenient and rapid iteration, reduce operating costs

Centimeter level positioning

Run advanced differential algorithm, so that the positioning accuracy of centimeter level positioning accuracy.



C_RTK interface definition diagram

E-RTK uses the same module on both ends, its interface definition and indicator light are the same.

parameter settings

C-RTK parameter setting

- Before using the C-RTK parameters need to be set, please refer to the following settings
- Please connect the base station to the u-center software and click the View option to enter the icon in the box below Message View -> UBX -> MON -> VER, as shown in the following figure:



• Click UBX> CFG> PRT, set the C-RTK protocol to RTCM3, and click send to save the settings



 Click UBX> CGF> TMODE3 and set the mode to Survey-in mode to set the time and accuracy you expect.

File Edit View Player Receiver	Tools Window Help	
	× ■ × ■ ▼ ■ ◎ ◎ ■ ■ ₩ ■ ⊠ ■ ∞ ■ ₩	i
H W I C the table of t	UBX - CFG (Config) - TMODE3 (Time Mode 3)	模式 16*
PM (Power Management) PM2 (Extended Power Manag	Mode 1 - Survey-in	时间
PMS (Power Management Set PRT (Ports)	Minimum Observation Time 200 [s]	- 空位桂庄
PWR (Power) RATE (Rates)	Required Position Accuracy 2.0000 [m] Survey-in ends if BOTH conditions are met!	~ 正世相反
RINV (Remote Inventory) RST (Reset)	└── Fixed Position	
	× 0.0000 [m]	
- TMODE (Time Mode)	Y 0.0000 [m]	
TMODE2 (Time Mode 2)	Accuracy 0.0000 [m]	
- TP5 (Timepulse 5) - TXSLOT (Tx Time Slots) - USB (Universal Serial Bus)	Use Lat / Lon / Alt Position	
- ESF (External Sensor Fusion) - HNR (High Navigation Rate)		
	点击 send 保存参数	



Click UBX> CGF> Set the MSG parameters as shown below

Change the same parameter to 1077, tick usb



Change the same parameter to 1087, check



Change the same parameter to 1230, check usb.



Set the base station to complete, please connect the mobile terminal and u_center, set the mobile terminal



Set the base station to complete, please connect the mobile terminal and u_center, set the mobile terminal

COM172 - u-center 8.26 - [Messages	- UBX - CFG (Config) - PRT (Ports)]	- 33
🕵 <u>F</u> ile <u>E</u> dit <u>V</u> iew <u>P</u> layer <u>R</u> eceiver	r Iools <u>W</u> indow <u>H</u> elp	E ×
D 🖬 🖨 🕶 🖓 🖪 👔 🕯 💼 🚺	20	
•• ▼ M ▼ 🌂 🎇 📇 📇		
	J	
in for the test and and		
ESFGW1 (Gyro+Wheeltick)	UBX - CFG (Config) - PRT (Ports)	Â
EIXCE (External source coming		
EXN (Fix Now Mode)	Target 1 - UART1	
- GEOFENCE (Geofence Config	Protocol in 0+1+5 · UBX+NMEA+RTCM3	
- GNSS (GNSS Config)	Protocol out 们 UBX 工作UDX	
- HNR (High Nav Rate)		
INF (Inf Messages)	Baudrate 9600	
- ITFM (Jamming/Interference I		
LOGFILTER (Log Settings)		
MSG (Messages)		
NAV5 (Navigation 5)		
NAVX5 (Navigation Expert 5)		Е
- NMEA (NMEA Protocol)		
-ODO (Odometer/Low-Speed 📰		
PM (Power Management)		
- PM2 (Extended Power Manaç		
PMS (Power Management Se	Evidended TV (impacit () -P) (7.00)	
PRT (Ports)	TX-Readu Feature (SERV7.00)	
PWR (Power)	Enable	
RATE (Rates)	Inverse Polarity (low-active)	
RINV (Remote Inventory)	Threshold 0	
RST (Reset)		
RXM (Receiver Manager)	P19早友10 二	
	NV11	-
) 🗙 🖹 Sena 🚰 Poll 🕃 🛍		
idy	u-blox M8/8 🖝 COM172 9600 No file open NMEA 02:12:5/ 02:09:5	i 🖉 /

Open Receiver> Action> SAVE config to save the configuration



C-RTK setting completed.

Flight control parameter setting

Flight control connected to the mission pInner "debug / configuration> all parameters tree" rtk GPS serial port serial parameters inserted serialx_BAUD (x serial number, GPS serial port serial3; GPS2 serial4) to 115, click

write.



The pictures shows above the rtk gps inserted into the flight control serial / serial5 (flight control interface identification) setting method

Flight Control Connection on mission plnner Commissioning / Configuration> All Parameters Tree> Set the following parameters

RTK as GPS2:

GPS+GLONASS+SBAS GPS_GNSS_MODE2 to 67 (if rtk is GPS2) is set to GPS + GLONASS + SBAS

GPS_TYPE2 is changed to 2 (if rtk is GPS2) to UBOX mode

RTK as GPS:

Change GPS_GNSS_MODE to 67 (if rtk as GPS) to GPS + GLONASS + SBAS

Change GPS_TYPE to 2 (if rtk is GPS) to UBOX mode

GPS_TYPE changed to 1 (such as rtk as GPS) Turn on GPS2

Mission Planner 1.3.52 bui	ild 1.3.52.0 ArduPlane V3.7	.1 (22b5c415)	1.00	-		
						0 • • Disconnect
Flight Modes	Command	Value	Uni t	Range	Description	Load from file
Basic Tuning	🗖 GPS					Save to file
Standard Params	GPS_AUTO_CONFIG			O:Disables automatic con…	Controls if the autopilot should automatically configure the GPS based on the parameters and default settings	Write Params
Advanced Params	GPS_AUTO_SWITCH			O:Disabled 1:VseBest 2:B…	Automatic switchover to GPS reporting best lock	Refresh Params
Full Parameter List	GPS_GNSS_MODE	0		O:Leave as currently con…	Bitmask for what GMSS system to use on the first GPS (all unchecked or zero to leave GPS as configured)	Compare Params
Full Parameter Tree	GPS_GNSS_MODE2	67		O:Leave as currently con'''	Bitmask for what GMSS system to use on the second GPS (all unchecked or zero to leave GPS as configured)	
	GPS_INJECT_TO	127		O:send to first GPS 1:send to***	The GGS can send raw serial packets to inject data to multiple GPSes.	All Units are in ra format with no scali
Planner	GPS_MIN_DGPS	100		O:Any 50:FloatRTK 1…	Sets the minimum type of differential GPS corrections required before allowing to switch into DGPS mode.	
	GPS_MIN_ELEV	-100	deg	-100 90	This sets the minimum elevation of satellites above the horizon for them to be used for navigation. Setting this to -100 leaves the minimum elevation…	Last Present
	GPS_NAVFILTER			0:Portable 2:Stationary	Navigation filter engine setting	Reset to Default
	GPS_RAW_DATA			O:Ignore 1:Always log…	Handles logging raw data: on uBlox chips that support raw data this will log RXM messages into dataflash log: on Septentrio this will log on the equipm***	Search
	GPS_SAVE_CFG			O:Do not save config 1:Save…	Determines whether the configuration for this GPS should be written to non- volatile memory on the GPS. Currently working for UBlox 6 series and above.	
	GPS_SBAS_MODE			U:Disabled 1:Enabled 2:N…	This sets the SBAS (satellite based augmentation system) mode if available on this GFS. If set to 2 then the SBAS mode is not changed in the GFS. Oth…	
	GPS_SBP_LOGMASK	-256		0:None (0x0000) -1:All (0xFFF	Masked with the SBP msg_type field to determine whether SBR1/SBR2 data is logged	
	GPS_TYPE			U:None 1:AUTO 2:uBlox 3:MTK***	CPS type	
	GPS_TYPE2	2		O:None 1:AUTO 2:uBlox 3:MTK***	GPS type of 2nd GPS	
	E GROUND					
					·	

Trial tutorial

Tutorials Using the Mission Planner for Satellite Search / Mobile Station Location This tutorial uses the Mission Planner ground station software and the Arducopter-3.5 UAV firmware. If you are using PX4 firmware and QGroundControl ground station software, refer to the link:

https://docs.px4.io/en/advanced_features/rtk-gps.html.

i) Please prepare the following hardware devices before

use:





Please follow the instructions below to connect the hardware: Please put the two ends of the antenna into the module; The base station module is connected to the USB port of the computer through the type c cable; a data transmission module is connected to the other port of the computer.

Mobile: C-RTK mobile station 6P line connected to the flight control GPS interface; 4P line connected to the ser4 / 5 interface; digital module connected to the TELEM (radio) interface





Please use the base station placed in the outdoor environment with sufficient sky coverage, in order to obtain a good satellite signal. Place the base station on a stable and elevated platform, such as a tripod.



Mission Planner Base station settings

First base station settings. During base station setup, the mobile and UAV flight controls need not be turned on. Open the Mission Planner ground station software on your computer and go to the initial setup -> Optional Hardware -> RTK / GPS Inject page (if you do not have this interface please update the mission plnner to the latest version), you You will see the following page

Mission Planner 1.3.52 bu	ild 1.3.52.0 APM:Copter V3.5.4 (cd25	c11)			
			JPILOT	DM123 _ 57600 封接统计COM123-1-QVADROTOR	
Install Firmware	COM3 Connect	Link Status. Input data rate 0 bps:put data rate	0 bps sent		
Wizard	115200 -	Messages Seen			
>> Mandatory Hardware	🗹 Inject MSG Type	L			
Frame Type		Base 📕 Gps 📕 Glonass 📕 Beidou 📕			
Accel Calibration	M8P autoconfig	KICM Base			
Compass					
Radio Calibration					
Servo Output					
ESC Calibration					
Flight Modes					
FailSafe					
>> Optional Hardware					
RTK/GPS Inject					
Sik Radio					
Battery Monitor					
Battery Monitor 2					

Select the correct base station port in the upper left and click connect. In the SurveyIn Acc column, enter the absolute geographic accuracy that you expect your C-RTK base station to achieve. In the Time field, enter the minimum search time you want. Click Restart, the ground station will be your input data transmission to the C-RTK base station, the base station will start a new round of search satellite positioning work. You will see the following page: During the search process, the box to the right of the Mission Planner page displays the current search

Mission Planner 1.3.46 b	uild 1.1.6310.11669		- o ×
		Menu	
Install Firmware	COM16 - Stop Link Status-	ta 509 hne-mut data rata 0 hne-cant	1
Wizard	115200 Messages See	Ubx0215=12 Ubx0138=12 Rtcm1230=2 Ubx0213=15 Ubx0501=2 Rtcm1074=10 Ubx0107=12	
>> Optional Hardware	✓ Inject MSG Type		실 ㄱ
RTK/GPS Inject	Base Gp	s 📕 Glonass 👥 Beidou	
Sik Radio	MSP autoconfig		<u></u>
PX4Flow	☑ MSP fw 130+		Survey In
Bluetooth Setup	SurveyIn Acc(m) ³ Time(s) ¹²⁰ Restart	Save Current Pos	In Progress Duration: 12
Antenna Tracker	Lat/ECEFX Long/ECEFY Alt/ECEFZ	Name Use Delet	Observations: 12 Current Acc: 15.4186

position:

1)Position is invalid: The base station has not reached a valid position yet

2)In Progress: The search star is still in progress. Duration: The number of seconds the current star search task has been executed.

3) Observation: The number of observations obtained

4)Current Acc: The absolute geographic accuracy that the current base station can achieve.

5) Mission Planner The green bar below the Mississippi Planner shows the satellite and satellite

signal strengths found by the current base station. Base station takes a certain amount of time to search for the accuracy of your input requirements. After testing, it takes a few minutes to reach an absolute accuracy of 2 m in an open and unobstructed area, and an absolute accuracy of less than 30 cm can take about an hour, and precision within 10 cm can take hours. It should be noted that the absolute geographical accuracy of the base station here will affect the absolute geographical accuracy of the base station here will affect the absolute geographical accuracy of the mobile station. If your application does not require a drone with a high degree of absolute geographic accuracy, you do not need to set the accuracy of the base station too high, resulting in a long satellite search time. Even if the accuracy of the base station is $1.5 \sim 2m$, the position accuracy of the mobile station can still reach the centimeter level.

After the C-RTK Node finishes its search, the Mission Planner will display the following page:



The figure shows that the status of the base station is green and both the GPS and Glonass systems are green (if you want to change the satellite system, please refer to the later chapters). The box on the right shows Position is valid.

Store the current position in the Mission Planner: Click Save Current Pos, enter a name in the dialog, and click OK. As shown below, you can see where you saved the list. Click the Use button corresponding to the location you saved, the base station will enter the fixed-point mode, the box on the right shows the status of Using FixedLLA. In the future, when you set up a base station in the same location, you do not need to search again, just click the Use button corresponding to your storage location.



Mobile Station Settings

After the base station is set up, you can turn on the drones. Connect the same mission planner ground station with the matched data transfer module. The data of the base station will be transmitted to the C-RTK mobile station on the UAV through the data transfer module. In the main page of the Mission Planner, you can see that the UAV's current GPS status is RTK Float / RTK Fixed / 3D RTK, indicating that the UAV's positioning has entered RTK status.

RTK Float for the floating point solution.

RTK Fixed is a fixed solution.

RTK Fixed has a higher accuracy, high environmental requirements, the signal is good enough,
positioning can enter the RTK Fixed state. 3D RTK is the Chinese version of Mission Planner RTK
Float / RTK Fixed unified
display.



Upgrade the firmware

1)The default firmware version for the C-RTK module is ublox-1.40 firmware. Compared to the previous version of the firmware

2)Added Glonass / beidou and GPS integration for RTK operation, which effectively improves RTK positioning. The ublox-1.40 firmware has also been released during the preparation of this operating manual.

3)Added functionality for mobile base stations where base stations need not be stationed in one place and can be moved at any time during use. For example, a base station may be placed on a moving car or boat.

4) The default firmware is already relatively new firmware, so generally do not have to upgrade

the firmware, in order to adapt to future firmware updates, the following to explain the firmware upgrade.

U-centreDownload and install U-center

Download software, please click the official website link

Then follow the prompts to install U-center software. During the installation, you will be prompted to install the driver, make sure that only check the Standard Driver For Windows, and then click on the step, follow the prompts to install, as shown below.

u-center_v8.24 安装	
iccate, communicate, accelerate	选择组件 选择你想要安装 u-center_v8.24 的那些功能。
勾选你想要安装的组件, 续。	并解除勾选你不希望安装的组件。 单击 [下一步 0M)] 继
选定安装的组件:	Drivers U-blox GNSS Standard Driver for Windows U-blox GNSS Sensor Device Driver for Wir Don't install Driver
	۲ III. ۲
所需空间: 21.1MB	描述 停悬你的鼠标指针到组件之上,便可见到它的描述。
	<上一步(P)下一步(M) > 取消(C)

Visit the official website firmware interface, download the required firmware and extract, as shown below

https://www.u-blox.com/en/product-resources?f	%5B0%5D=field_file_catego	ry%3A223&f%5B1%5D=	propei 🔯 🚖 🐔 👻	😵 🗸 百度 🛛 🤇
Cublox	Q Products Support Inne	How to buy Careers	Contact us Partner Login estors My account	English ~ 🔝
Home > Support > Product resources				
Product reso	urces			
If you require technical support or need to ask please select the appropriate option below:	k questions and receive answers	from other members of th	ne community forum, relating	to the product,
Customer forum Support for	orm	Down	nload files	¥ 3
Product category	Firmware Update	2		
Desition & Time (1)				ГЪ
File category	u-blox M8 Flash Firm Precision GNSS prod	ware 3.01 HPG 1.40 - ucts. NEO-M8P and C9	ONLY for High 4-M8P (NOT for	ZIP 932 KB
Firmware Update White Paper (7) Driver (3)	Standard Precision, T (2017 06 29)	iming or Dead Reckonir	ng products)	



Connect C-RTK Base Station / Mobile Station to PC as shown below:

Upgrade Procedure Open the U-center software and click the Connect button (as shown in the red circle below) to select the corresponding computer port of the base station / mobile station to be upgraded.



Select tools-> u-blox 5-8 Flash Firmware Update and click the red box below to find the corresponding file

🕐 COM172 - u-center 8.26 - [Chart - [Alt (HAE) (m) / Index]]	
💽 File Edit View Player Receiver Tools Window Help	_ 8 ×
↓H ()w ()c 135 135 (a) ↔ ↔	
	×
u-blox 5 - 8 Flash Firmware Update	Longitude Latitude
Firmware image	Altitude TTFF
│d:\用户目录\Desktop\NE0-M8P-FW301-HPG140_RNwithFW\DC	Fix Mode Hore R
Flash definition file (needed for generations 5 / 6)	2D Acc. [m] PDOP
	HDOP Satellites
Flash Information Structure (FIS) file (needed for generations 7.7.8.7 Ma C:\Program Files (x86)\u-blox\u-center_y8.26\flash.xml	
Use this Baudrate for update USB alternative update method	
□ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □	
I Send Training sequence	
OK Cancel	
Image: Image	

Base station selection

is:UBX_M8_301_HPG_xxx_REFERENCE_NEOM8P2.59a07babb501ba6a89ff87cac2f 2765f.bin

Base station selection

is:UBX_M8_301_HPG_xxx_ROVER_NEOM8P0.3ee86a9e4775e3335e742b53527fa5 d0.bin (X is the corresponding version number)

Select Flash.xml in the Flash Information Structure (FIS) File, and Flash.xml is under U-center's installation directory, U-center_vx.xx-> flash.xml. (X is the software version number)

Click OK, wait for the firmware to finish recording. Burn generally takes only about a minute or so. If the programming is successful, the upgrade interface is displayed in green; if the upgrade is aborted, the interface is displayed in red. If the programming process is interrupted, or for a long time it does not respond, you need to re-power on, press the operation to burn once.

Confirm the base station / mobile station's current firmware version

When the base station / mobile station is connected to the U-center, click on the View

tab and go to Message View -> UBX -> MON -> VER, as shown in the following figure:



As shown in the figure, the current firmware version is FWVER = HPG 1.40 REF, and REF indicates the current firmware version is the base station.

Use GPS + Beidou

uBlox 1.30 firmware default GPS + GLONASS navigation system for positioning services. If you want to change to GPS + Beidou navigation system, you need to enter the Messages view -> UBX -> CGF -> GNSS directory, GLONASS Enable option to cancel the tick, and then check the Beidou Enable option. After the election, click send to complete the change.

UVILIZ - U-center 8.20						<u> </u>	
File Edit View Player Receiver Tools Wind	low Help						
D 🖬 😅 🕶 🚳 🖪 🐰 🖪 💼 🚳							
					3		
					•		
		- →					
🖡 🕼 🕼 號 🏙 🏟 🏘 🏘							
	Carefai					·	×
DVNICTED (Description County) - GINSS (GINSS	Config)					Longitude	l
	UBX - CFG (Config)	- GNSS (GNS	S Config)			Altitude	
ESFGWT (Gyro+Wheeltick)				Channels		TTFF Fix Mode	Notes
ESRC (External Source Config)	ID GNSS	Configure	Enable	min ma	ax Signals	3D Acc. [m]	
FIXSEED (Fixed Seed)	0 GPS	•	$\overline{\mathbf{v}}$	8 16	🔽 🔽 L1C	PDOP	
FXN (Fix Now Mode)	1 SBAS		Г	0 0	— г. L1С	Satellites	RANA S'ANA
GEOFENCE (Geofence Config)	2 Galileo		Γ	0 0	E1		
GNSS (GNSS Config)	3 BeiDou	$\overline{\mathbf{v}}$	$\overline{\mathbf{v}}$	8 16	₩ B1		
HNR (High Nav Rate)	4 IMES		Г	0 0			
ITEM (Immine /Interference Menite	5 QZSS		Г	0 3		=	
- LOGELITER (Log Settings)	6 GLONASS	v	•	8 14	🗌 🔽 L10		
	7 IRNSS						
NAV5 (Navigation 5)							
NAVX5 (Navigation Expert 5)	Number of channels	: available		28			
NMEA (NMEA Protocol)	Number of channels	to use		28	Auto set		
ODO (Odometer/Low-Speed COG f							
PM (Power Management)	For specific SBAS c	onfiguration u	se				
PM2 (Extended Power Managemen		57.0					
PMS (Power Management Setup)							
PKI (Ports)						1.04	
└└──── 友送	•				- 111		
A X Bend Poll & B .	1					-	
Ready	u-blox M8/8	■ COM172	9600 N	o file open	UB	X 00:28:4! U	тс



Open Receiver> Action> SAVE config to save the configuration

Note: The base station and rover must have the same settings, use the same navigation

system configuration, or can not enter the RTK.