Description of the Access Control Settings on the Device MENU

MENU → ACS

1. D-Lock

Item	Settings	Description
Open Delay	5	You could set it from 0 – 255seconds
Check Door Status	No	Default is NO, **when you need to use the alarm function, need to set it to "Yes".**
Open Overtime alarm	No	Default is NO, when you use the alarm, you need to set it to "YEs". Sample: we set "Open Delay" to 5seconds. Check Door Status "Yes", Open Overtime alarm "Yes", when someone get through the door and keep it open for more than 5 seconds, it will active the alarm.
Illegal open alarm	No	Block
Enable Relay Alarm	No	Block
Fire Alarm	No	Block
Wiegand	34	

2. Hijack

Item	Settings	Description
Enable Anti - hijack	NO	Default is NO, when we need to use this function, we set it to "Yes". Sample: we set the Hijack FP NO. as 2, so when someone threaten me to open the door. I could use the fingerprint 2 (it means the 3rd fingerprint i enroll in the device.) for authentication, and the door will be open, and there's a alarm to inside the people inside that there's threaten outside.
Hijack FP NO.	2	Fingerprint NO.
Open Door	Yes	When use the hijack FP for authentication, the door will be open. We could set it to no.
Alarm	NO	There's alarm to inform the people inside.